

EXIT SIGN INSTALLATION INSTRUCTIONS

Frame Components and Initial Construction



Components:

- 2 – Short frame sections
- 2 – Long frame sections
- 4 – Corn



- 4 – Set Screws
- 4 – Spacers
- 1 – 3/32" Allen wrench



1. Insert the 4 corner keys into short frame section's ends.



2. Using the Allen wrench, hand-tighten the set screws to secure the 4 corner keys.



3. Position the long frame sections with screw hole counter sinks facing up.



4. Slide the long frame sections onto the corner keys of the short frame sections using firm pressure. Hand tighten the set screws as shown.

Flag and Ceiling Mounting



1. Remove the top and bottom set screws from one end of each long frame section. Pull the short frame section away from frame assembly.



2. Slide the EXIT sign into the first groove of the frame. For double sided exit signs, slide each exit sign into its own groove with exit lettering facing outward.



3. Reinstall the short frame section into the frame assembly. Align the EXIT sign(s) into the frame groove(s). Hand tighten the set screws.



4. Using the mounting bracket as a template mark the position of the mounting screws on the ceiling or wall.



5. Secure the mounting bracket using proper hardware and techniques



6. Safely snap fit the framed EXIT sign into the secured mounting bracket.

Surface Mounting



1. Using the assembled frame as a template, position the frame and mark the 4 attachment locations. Install proper anchoring hardware as necessary.



2. Position the frame with the counter sunk hole surfaces facing you. Place screw spacers between the wall and the frame while inserting the mounting screws. Hand tighten the screws into the wall or proper anchor if used.



3. Loosen the top and bottom set screws from one end of each long frame section. Pull the short frame section away from frame assembly.



4. Slide the EXIT sign into the assembly. Reinstall the short frame section into the frame assembly. Align the EXIT sign into the frame section groove. Hand tighten the set screws.



5. Apply directional arrows by removing the protective plastic layer. For left exit paths apply arrow on the left. For right exit paths apply arrow on the right. If exit path is straight no arrows are needed. If exit paths are located on both left and right apply both arrows.



GENERAL INSTALLATION GUIDELINES FOR PHOTOLUMINESCENT EXIT SIGNS

UNFRAMED SIGN INSTALLATION:

All unframed signs will be provided with pre-drilled mounting holes.

1. Verify that the desired mounting location has the required 5FC of light as required by code.
2. Mark mounting holes on the wall where the exit sign is to be mounted. Drill out mounting holes.
3. Use appropriate anchoring as required by the wall materials being used and local governing building codes.
4. Remove any plastic protective film from the back and front of sign before mounting.
5. Mount the exit sign and screw into place.

CAUTION: When mounting signs from the ceiling and walls, please use cautionary measures to ensure that signs are mounted high enough to avoid creating head hazards for tall occupants.

Warranty, Exclusive Remedy and Disclaimer: We warrant to our customers that our products shall be free from defects in material and workmanship for a period of up to five (5) years, or as otherwise noted, from the date of original shipment to our customers. Any warranty claim must be asserted within the applicable warranty period; thereafter the claim will not be honored. The exclusive remedy against us for a warranty claim or otherwise shall be limited to repair or replacement of the products shown to have been defective and returned (at customer's cost) to us or an authorized service center. Abuse, misuse, or improper installation voids this warranty as well as the exclusive remedy. Our sole and maximum liability for a defective product shall never exceed the cost of the subject product. Except for such warranty and exclusive remedy as stated, WE DISCLAIM ALL OTHER WARRANTIES WITH RESPECT TO OUR PRODUCTS, WHETHER EXPRESS OR IMPLIED (EXCEPT FOR THE EXPRESS WARRANTY OF TITLE), AND WE SPECIFICALLY DISCLAIM THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

In no event shall we be liable to the customer in warranty, contract, strict liability or otherwise for any damages alleged to be caused by one or more of our products beyond the cost to the customer of the subject product or products, refund of the purchase price being the customer's sole and exclusive remedy against us upon proof of any alleged claim. Incidental or consequential damages, including labor costs relating to installation or removal, shall not be our liability regardless we knew or should have known of any general or particular requirements for our products and the customer shall not have any remedy against us for such damages, the sole and exclusive remedy for a proven claim having been stated above. We shall have no liability whatsoever for incidental, indirect, special or consequential damages of any kind.

*****Ceiling and walls made of different materials require different types of fasteners. Use fasteners suitable for the ceilings or walls in your building**

Always install products in compliance with your local building code. Check your local code before you install any sign to ensure your installation meets all criteria.